

WLA00003

EN



## KL-3

Smart LED head light with Bluetooth® connectivity. Boost mode enables up to 1000 lumens. Optisense Technology self-adjusts to various lighting conditions. Attaches to all KASK helmets via the head strap or included overhead band enabling use with eye, face, or hearing protection.

## TECHNICAL DETAILS

Weight incl. Battery	179 g
Maximum light output boost	1000 lm
Light output max - min	750 lm (li-ion only) - 10 lm
Runtime max - min	100 h - 4 h
Battery	1* Li-ion (included) or ICR Li-ion 3.7V (not included)
IP class	IP54
Charging time	420 min*
Light functions	Boost, power, mid power, low power, blink, SOS, strobe
Functions	Low battery warning; charge indicator; battery indicator; rapid focus; transport lock; red, green, and blue light; Bluetooth; automatic brightness adjustment

## TECHNOLOGIES



### ADVANCED FOCUS SYSTEM®

Patented technology that allows a seamless transition from broad low beam to sharply focused high beam.



### RAPID FOCUS

Mechanism that allows the light beam to be adjusted quickly.



### DUAL POWER SOURCE

Equipped with two battery types; a rechargeable lithium-ion battery and regular AA alkaline battery, to provide flexibility in a variety of applications.



### MAGNETIC CHARGE SYSTEM

Easily recharge the lithium-ion battery via a magnetic USB cable.



### COOLING TECHNOLOGY

Designed to dissipate heat.



### TRANSPORTATION LOCK

Prevents the light from being turned on inadvertently.



### GREEN LIGHT

Equipped with a green LED light for increased run time and nighttime visibility.



### BLUE LIGHT

Equipped with a blue LED light for use in fog and smoky conditions.



### RED READING LIGHT

Equipped with a red LED light for better nighttime visibility and emergency situations.



### EMERGENCY LIGHT

Designed to turn on automatically when the power goes out and the headlamp is on its charging station.



### OPTISENSE® TECHNOLOGY

Technology that automatically adapts to the present light conditions—controlling the luminosity based on the reflecting surrounding light to avoid glare.



### TEMPERATURE CONTROL SYSTEM

Technology that automatically lowers the output to protect from overheating.



### BLUETOOTH®

Designed with Bluetooth® smartphone connection via app for personalized settings, timer, etc.

## ADDITIONAL INFORMATION

### GUARANTEE

2 years from the date of purchase.

### CLEANING

Use a damp clean cloth and dry carefully. Do not use chemical detergents, solvents, petrol powders as they are too aggressive and could lower the structural resistance of the components.

2  
YEARS  
GUARANTEE

## HEADLAMPS COLLECTION



WLA00001  
KL-1



WLA00002  
KL-2



WLA00003  
KL-3

## DISCOVER MORE



SCAN FOR  
COMPLETE  
COLLECTION